


# INSTALLATION MANUAL






This item is no longer needed for installation

## WARNING!


Severe personal injury and property damage can result from improper installation or assembly. Read the following warning carefully before beginning.

- If you do not understand the instructions or have any concerns or questions, please contact a qualified local installer.
- Do not install or assemble if the product or hardware is damaged or missing. If you require replacement parts, please contact your local distributor for assistance.
- This product fits most 32"-65" LCD/plasma screen; maximum weight of LCD/plasma screen: 100 lbs/45KG; Lower shelf max load: 10 lbs/4.5kg.
- Do not use this product for anything other than the original design.
- This product contains moving parts, please use with caution.




## Supplied Parts List


### Accessories:




## Screw package list For Tv Set Mounting:




## Screw package list for TV Stand Mounting:




## Step 1 The installation of base and column




## Step 2 Height adjustment of column by pin lock



## Step 3 Installation of the lower shelf





## Step 4 Installation of the upper shelf






## Step 5 Installation of TV and hook


▲ Use The Right Screw; Leave Suitable Distance Between The Screw And The TV.



## Step 6 Installation of TV and Stand



## Step 7 Management of cable



## Step 8 Product's Specification

